
2013 CC Quick-Start Guide





The information within this guide must be used in conjunction with the information in the Volkswagen Owner's Manuals. Refer to your vehicle's Owner's Manual for all information and warnings. By using this guide, you acknowledge that you are aware of and have read the warnings and information provided in the Owner's Manual on the topics in this guide and will use this information to augment that material.

At Volkswagen, we want to be sure you get the most out of your time behind the wheel, so we've created this guide to take you through the finer points. And if you still have questions, just turn to the back of this guide and see how easy it can be to contact us. You'll see how fun and easy it is to drive a VW, and soon you'll be speaking fluent Volkswagen.



LEARN MORE AT **vw.com/cc2013**

Bluetooth® Technology



Text* PHONE to 50467 to watch the Bluetooth video. Message and data rates may apply.



*Do not text while driving.

Pairing your phone

First, check your phone's compatibility at www.vw.com/bluetooth.

Start the ignition. Your car's Bluetooth system will be in "discovery" mode for the next three minutes. (If your car is equipped with an RNS 315 touchscreen display, power it on.)

From the Bluetooth menu on your phone, search for new devices and select VW PHONE.

A connection request will appear on the multi-function display (or on the RNS 315).

Press OK on the steering wheel (or PAIR on the RNS 315).

The multi-function display (or your RNS 315 screen) will then show a PIN.**

Make sure the same PIN is displayed on your phone and press OK on the steering wheel (or press YES on the RNS 315). Then press PAIR on your phone.†

Reconnect Automatically

If your phone displays a prompt asking to connect to VW PHONE, make sure to enable future automatic connections.

**Some phones may require entering a four-digit PIN (0000) to complete the pairing process. †Once the PIN is shown, pairing must be completed within 30 seconds. Otherwise the process will need to be repeated.

Bluetooth Voice Recognition



Press the microphone button until you hear a chime. Your VW will say, "Main menu." Then take the following steps.



Text* VRECO to 50467 to watch the Voice Recognition video. Message and data rates may apply.

Call by name

After you hear a beep, say, "Call" followed by the name of the person you want to call. For example, "Call Mike Brown." The system will repeat your request. Say, "Yes" if correct. The system will answer, "Calling Mike Brown."

Redial

After the beep, say, "Redial."

Help

After the beep, say, "Help." Then follow the prompts.

Answer an incoming call



The Bluetooth system will interrupt your car stereo with a ringtone. Press the phone button on the multi-function steering wheel.





🔼 Important Warnings and Safety Information, which you must read, are listed on the last panel, under BLUETOOTH TECHNOLOGY WARNINGS.

^{*}Do not text while driving.

Premium VIII Audio



*Do not text while driving.



Select and save a preset radio station

Press FM, AM or SAT to select a band.

Use the tuning knob at the lower right to select a station, then press and hold any preset station soft key until you hear a confirmation beep.

The new station will appear in the display.

By pressing the Presets soft key, you can change through additional presets.

Streaming audio with Bluetooth® technology

First, pair your compatible Bluetooth equipped phone or audio player. (Refer to the pairing instructions in this booklet.)

Press the MEDIA hard key.

Press the BT-Audio soft key.

To navigate through your music, press the PLAY/PAUSE, PREVIOUS, and NEXT TRACK soft keys.



HD Radio® Programming. HD Radio is totally free programming, offering crystal clear sound—FM stations have CD-quality sound, while AM stations sound like FM stereo. HD Radio also offers more variety, as many FM stations broadcast extra HD multicast channels.

HD Radio Signal Interruption. When leaving the HD coverage area, HD1 channels will switch to the analog signal, while HD2/HD3 channels will cut off completely, without gradual fading. This is normal. The signal will refresh as you drive.

SiriusXM Satellite Radio. New Volkswagen vehicles come with a three-month trial subscription to the Sirius Select package. Infrequently, tall buildings and tunnels may interrupt the satellite signal. This is normal. The signal will refresh as you drive. For more information, please refer to the SiriusXM brochure in your glove box.

LEARN MORE AT VW.com/cc2013



M Important Warnings and Safety Information, which you must read, are listed on the last panel, under PREMIUM VIII WARNINGS.

Optional RNS 315 Navigation





Enter a destination

Press the NAV hard key.



Tap the flag icon on the touchscreen. This will allow you to enter the address.

Enter the state first, then the city, the street, and the number.

Not sure about the number of the address? You can just enter the state, the city, and the street. Then press the List soft key to display the street.

Confirm the address. If the address is incorrect, press the back button to return to the address entry screen.

Press the START soft key to begin your route.

Change the route settings

The system will automatically display the fastest route. You can also have the most economical or shortest route displayed.

Within the Navigation screen, press the SETUP hard key.

Choose ROUTE OPTIONS.

Choose ROUTE CRITERIA.

Now you can change from the Fast default to Economic or Short.

LEARN MORE AT VW.com/cc2013



M Important Warnings and Safety Information, which you must read, are listed on the last panel, under NAVIGATION WARNINGS.

iPod® Adapter

To connect your device, here's all you need to do.

RNS 315

First, note that your iPod music player must be Generation Four or newer.*

Connect it to your car's MDI cable.

Audio from your device will play through your speaker system.

To choose a song, press the LIST soft key, then the UP soft key. To display the category list, press the UP soft key again.



Premium VIII

First, note that your iPod music player must be Generation Four or newer.

Connect it to your car's MDI cable.

Press the MEDIA hard key.

Press the MEDIA-IN soft key until the external audio device is shown in the display.

To choose a song, press the Selection soft key.

To display the category, press the key with the folder icon at the upper left of the screen.

To return to the main screen, press the Back soft key on the upper right corner of the screen.

*For more information on iPhone 5, please visit vw.com/cc2013

Playing your media device with the auxiliary jack



Premium VIII

- Press the SETUP hard key.
- Press the MEDIA soft key.
- Press the Enable AUX Input soft key.
- Press the MEDIA hard key.



RNS 315

- To toggle between different media, such as a CD or streaming audio from your phone, press the MEDIA hard key.
- Then press the media-specific soft key.



LEARN MORE AT VW.com/cc2013



M Important Warnings and Safety Information, which you must read, are listed on the last panel, under iPOD ADAPTER WARNINGS.

Climatronic® Heating and Cooling



To cool or heat the interior

Turn the temperature dial to 72.°

Press the AUTO button.

Like a thermostat, the system will maintain the temperature.

In extreme heat, press the MAX AC button.

When a comfortable temperature has been reached, push the AUTO button again.



Defrost the windshield



- Press the MAX defrost button.
- The AC function comes on automatically to dry the air.
- When the windshield is clear, push the AUTO button to return to your automatic climate control settings.

Set and synchronize temperatures for driver and passenger

The driver turns the left dial until the desired temperature is shown above the dial.

The passenger can choose a different temperature by turning the right dial.

The passenger's temperature can be synchronized with the driver's temperature by pressing the SYNC button. When the light is on, SYNC is activated.

LEARN MORE AT VW.com/cc2013



Cruise Control



Activate



Pull the cruise control stalk toward you. The speedometer icon will appear in the multi-function display.



Set cruising speed

When you get to your cruising speed, press the SET button at the end of the stalk.

Your speed will appear next to the speedometer icon.

The green CRUISE light will appear in the instrument cluster.

To increase/decrease your speed to the nearest increment of 5, tap the stalk up or down.



Cancel and resume

- To cancel and resume cruise speed, press the brake pedal or slightly push the stalk away from you.
- The CRUISE light will go off.
- To resume, pull the stalk towards you. You'll resume cruising at your saved speed.

Your most recently set speed will appear as a small icon in the multi-function display. It will remain in memory until you turn your VW off.

LEARN MORE AT VW.com/cc2013



Important Warnings and Safety Information, which you must read, are listed on the last panel, under CRUISE CONTROL WARNINGS.

Key Fob Programming



Customize which doors lock or unlock when you press the key fob

First, make sure your vehicle is parked. Your car won't let you do this while you're driving.



Press the button with the menu icon located on the steering wheel until you see the "Settings" screen on the multi-function display.

Press the down arrow to scroll to "Convenience." Press OK.

Scroll down to "Central Locking"—press OK.

Press "Unlock doors" to adjust which doors lock or unlock when the key fob is pressed once.

"All doors" unlocks all doors.

"Single door" unlocks only the driver's door.

"Vehicle side" unlocks the doors on the driver's side of the vehicle.

Press the up or down arrows to select an option.

Press OK to select your preference.





Program the doors to unlock when you remove the keys from the ignition

First, make sure your vehicle is parked.

Press the menu button on your steering wheel until you see the screen labeled "Settings" on the multi-function display.

Press the down arrow to scroll to "Convenience"—press OK.

Scroll down to "Central Locking"—press OK.

Select "Automatic"—press OK.

Select "Unlock," press OK, and make sure the box is checked.

From now on, when you remove your keys from the ignition, the doors will automatically unlock.

vw.com/cc2013

M Important Warnings and Safety Information, which you must read, are listed on the last panel, under KEY FOB WARNINGS.

Windshield Wipers

Continuous

LOW: From the OFF position, move the wiper stalk two clicks up.

HIGH: From the OFF position, move the wiper stalk three clicks up.

Pulsing/quick wipes

From the OFF position, press the wiper stalk down for a single wipe.

Press and hold the wiper stalk down for two seconds for a faster wipe.

Wash

Pull the stalk toward you to spray washer fluid.



Use the rain-sensing wipers

From the OFF position, move the wiper stalk one click up to activate the rain-sensing wipers. The rain sensor automatically turns on the wipers when it begins to rain, adjusting the wiper frequency in line with rainfall intensity.

NOTE: Be sure to turn off the rain-sensing wipers before going through a car wash.



🔼 Important Warnings and Safety Information, which you must read, are listed on the last panel, under WINDSHIELD WIPER WARNINGS.

Tire Pressure Monitoring System







Seeing the TPMS light? Here's what to do.

The correct tire pressure is displayed on the sticker on the driver's door jamb. Inflate your tires to those specifications, not to the number on your tires.

If you see the TPMS light on your instrument panel or the message "tire pressure too low" in the multi-function display, use the right menu button on your steering wheel to show Vehicle Status on the display. This will show the current and recommended tire pressure.

Inflate the low tire(s) to the correct pressure as soon as possible.

Cooler temperatures may cause a warning to appear and then disappear as the tires warm up. This is a good reminder to check and adjust the tires to the proper inflation pressure.





Marnings and Safety Information, which you must read, are listed on the last panel, under TPMS WARNINGS.



▲ Important Safety Warnings

BLUETOOTH® WARNINGS

- Collisions and injuries can occur if the driver is distracted. Speaking on or using a phone while driving can distract the driver from traffic.
- Select the volume settings so that the acoustic signals from the outside are still audible (for example, the sirens of emergency rescue vehicles). Observe legal regulations.
- In areas with no or poor mobile network coverage and possibly in tunnels, garages and subways, phone conversations may be interrupted, and it may be impossible to make phone calls-even emergency calls!
- In some countries, emergency calls may only be supported when the mobile phone is connected to a mobile phone package which has a SIM card that is "not blocked" and/or has sufficient credit on it.
- · Unmounted or improperly mounted mobile phones can fly around in the event of a sudden driving or braking maneuver or a collision. This may cause injuries.
- Never place or mount a mobile phone on doors, on the windshield or on or near the area on the steering wheel marked "AIRBAG," the instrument panel, the seat backrests or the areas between these points and the driver/passengers. Mobile phones can lead to serious injuries in cases of collisions, especially when the
- · Always switch off your mobile telephone at gas stations or wherever there is a fire or explosion hazard. Electromagnetic radiation can cause sparks which can
- The mobile phone will automatically connect to the mobile network when the Bluetooth connection to the mobile phone package is disconnected.
- Using a radio device in the vehicle without a connection to an external antenna might exceed electromagnetic radiation thresholds. This also applies if the external antenna is not installed properly.
- Keep a distance of at least eight inches between the antennas of the mobile phone and the pacemaker, since mobile phones can affect the functionality of a nacemaker
- Do not carry a mobile phone on standby mode in the breast pocket directly on top of a pacemaker.
- If interference is suspected, immediately switch off the mobile phone.

 Always keep the armrest closed while driving. The center armrest can interfere with the driver's elbow movement and thus cause collisions and severe injuries.

CLIMATRONIC® WARNINGS

Poor visibility increases the risk of collisions and other accidents that cause serious nersonal injuries

- Always make sure all windows are clear of ice, snow, and condensation for good visibility to the front, sides, and rear.
- Maximum heating output and fast defrosting will only be possible after the engine has reached operating temperature. Wait until you have good visibility before
- Always make sure you know how to properly use the heating and ventilation systems as well as the rear window defogger that you will need for good visibility.
- Never use air recirculation for long periods of time. When the air conditioner is off and recirculation mode is on, condensation can quickly form on the windows and greatly reduce visibility.
- Always switch off recirculation mode when it is not needed. Stale air causes driver fatigue and reduces driver alertness, which can cause accidents, collisions. and serious personal injury.
- Never switch off the fan for a long period of time and never use air recirculation a long period of time because no fresh air will come into the passenger compartment.

CRUISE CONTROL WARNINGS

Using the cruise control when it is not possible to drive safely at a constant speed can be dangerous and can lead to an accident and serious personal injuries.

- Never use cruise control when driving in heavy or varying traffic or when you
- cannot keep a safe distance between you and the vehicles ahead of you. Never use cruise control on steep, winding, or slippery roads (such as gravel)
- roads, wet roads, or snowy or icy roads) or on roads with standing water. Never use cruise control when driving off-road or on unpaved roads.
- Always adjust your speed and the distance you keep between you and the vehicles ahead of you to the road, traffic, weather and visibility conditions.
- To help prevent unintended operation of cruise control, switch the system off when it is not being used.

- It is dangerous to use the Resume feature when the previously set speed is too high for the existing road, traffic, or weather conditions.
- When traveling downhill, the cruise control may not be able to maintain a constant speed. The vehicle may speed up because of its own weight. Downshift and/or use the foot brake to slow the vehicle.

IPOD® ADAPTER WARNINGS

Driver distraction, including the operation of external audio devices, can cause accidents and serious personal injury.

- Always focus your undivided attention on driving the vehicle.
- · Never display video images in the display when the vehicle is moving.
- Use the radio navigation system only if road, traffic, and weather conditions permit and you will not be distracted from your driving.
- Always obey applicable laws regarding the use of displays when the vehicle is moving
- Always adjust volume so that horns and warning sounds from outside the vehicle (police and fire truck sirens, for example) can be clearly heard at any time.
- Observe legal regulations.
- · Always drive attentively and responsibly.
- Setting the volume too high can damage the hearing. This applies especially to volumes above about 85 decibels.
- · Select volume settings so that acoustic signals from the outside are always audible (for example, the sirens of emergency rescue vehicles).
- Please lower the volume before changing or connecting to an audio source.
- . Unmounted or improperly mounted external devices can be thrown through the passenger compartment in the event of a sudden driving or braking maneuver or an accident, causing injury.
- Never leave external devices in the doors, on the front windshield, on or near the area marked "AIRBAG" on the steering wheel, instrument panel, seat backs, or between these areas and the occupants. External devices can cause serious injury in the event of an accident, especially if the airbags inflate.
- · Connecting cables of external devices may obstruct the driver.
- Route cables so as not to interfere with the driver. The armrest can affect the elbow room of the driver and thus cause accidents and severe injuries.
- · Always keep the armrest closed while driving.

KEY FOB WARNINGS

Improper use of vehicle keys can result in serious personal injury.

- · Always take the key with you when you leave the vehicle. It can be used to start the engine and operate vehicle systems such as the power windows, leading to serious personal injury. Children or other unauthorized persons could also lock the doors and the luggage compartment.
- Never leave children, disabled persons, or anyone who cannot help themselves in the vehicle. The doors can be locked with the remote control key. This could result in people being trapped in the vehicle in an emergency. For example, depending on the time of year, people trapped in the vehicle can be exposed to very high or very low temperatures.
- Heat build-up in the passenger and luggage compartment of a parked vehicle can result in temperatures in the vehicle that are much higher than outside temperatures, particularly in summer. Temperatures can quickly reach levels that can cause unconsciousness and death, particularly to small children.
- Never remove the key from the ignition switch while the vehicle is moving or rolling to a stop. The steering wheel will lock and you will not be able to steer or control the vehicle.

NAVIGATION WARNINGS

Operating the radio navigation system while driving can distract from traffic and lead to accidents.

- · Observe legal regulations.
- · Always drive attentively and responsibly.
- Setting the volume too high can damage the hearing. This applies especially to volumes above around 85 decibels.
- Select volume settings so that acoustic signals from the outside are audible (for example, the sirens of emergency rescue vehicles).
- . Inserting data media while driving can distract from traffic and lead to accidents. Always keep the storage compartment closed while driving.

PREMIUM VIII WARNINGS

Distracting the driver from traffic can lead to collisions and injuries. Using the radio system while driving can distract from traffic.

- · Observe legal regulations.
- Always drive attentively and responsibly.
- Setting the volume too high can damage the hearing. This applies especially to volumes above about 85 decibels.
- Select volume settings so that acoustic signals from the outside are always audible (for example, the sirens of emergency rescue vehicles).
- Please lower the volume before changing or connecting to an audio source. Unmounted or improperly mounted external devices can be thrown through the passenger compartment in the event of a sudden driving or braking maneuver or a collision, causing injury.
- Never leave external devices in the doors, on the front windshield, on or near the area marked "AIRBAG" on the steering wheel, instrument panel, seatbacks, or between these areas and the occupants. External devices can cause serious injury in the event of a collision, especially if the airbags inflate.
- Connecting cables of external devices may obstruct the driver. Route cables so as not to interfere with the driver
- The armrest can affect the elbow room of the driver and thus cause collisions and severe iniuries. Always keep the armrest closed while driving.
- . Injuries can be caused by invisible laser beams if the housing of the CD player is opened. Have the CD player repaired only by a specialist.

TIRE PRESSURE MONITORING SYSTEM WARNINGS

Incorrect tire pressures and/or underinflation can cause sudden tire failure, loss of control, collision, serious personal injury or even death.

- . When the warning symbol appears in the instrument cluster, stop and inspect
- Incorrect tire pressure and/or underinflation can cause increased tire wear and can affect the handling of the vehicle and stopping ability.
- Incorrect tire pressures and/or underinflation can also lead to sudden tire failure. including a blowout and sudden deflation, causing loss of vehicle control.

- The driver is responsible for the correct tire pressures for all tires on the vehicle. The recommended tire pressure values are listed on a sticker inside the
- The TPMS can only work correctly when all tires on the vehicle are filled to the correct cold tire inflation pressure specified for the tires installed on the vehicle.
- Using incorrect tire pressure values can cause accidents or other damage. Always inflate the tires to the correct specified cold tire pressure values for the tires installed on the vehicle.
- · Always maintain correct cold tire inflation pressure so that TPMS can do its job.
- Always inflate tires to the recommended and correct tire pressure before driving off.
- Driving with underinflated tires causes them to flex (bend) more, letting them get too hot, resulting in tread separation, sudden tire failure, and loss of control.
- Excessive speed and/overloading can cause heat build-up, sudden tire failure and loss of control.
- If the tire pressure is too low or too high, the tires will wear prematurely and the vehicle will not handle well.
- If the tire is not "flat" and you do not have to change a wheel immediately, drive carefully and at reduced speed to the nearest service station to check the tire pressure and add air as required.
- When replacing tires or wheel rims on vehicles equipped with TPMS always read and heed the information and all WARNINGS regarding Tires and wheels.

WINDSHIELD WIPER WARNINGS

Windshield washer fluid without enough frost protection can freeze on the windshield and reduce visibility.

- Use the windshield washer system with enough frost protection for winter temperatures
- · Never use the windshield wipers/washers when it is freezing without first defrosting the windshield. The washer solution may freeze on the windshield and reduce visibility.
- . Worn or dirty wiper blades reduce visibility and increase the risk of accidents and severe injuries.
- Always replace wiper blades that are worn, damaged, or do not keep the windshield clear.

Got questions? We've got answers.

Go to vw.com/cc2013

Visit our Volkswagen blog and you'll find plenty of how-to guides and maintenance videos.

Call 1-800-444-8982

Contact the Volkswagen Loyalty Center, and a friendly Volkswagen representative will be happy to assist you.

Owning a VW gets even better.

Call your VW dealer to make an appointment for a Second Vehicle Delivery within the first 90 days or 6,000 miles. At the appointment, we'll answer any questions you may have about your new Volkswagen, so you can get more out of your car.

Volkswagen Carefree Maintenance

As a Volkswagen driver, you can visit any VW dealer and receive routine maintenance like oil changes and vehicle inspections from certified techs that speak fluent Volkswagen.

Schedule your Second Vehicle Delivery by:

Month

Date

Year

